

## Tablet Station powered by Hublet Cleaning Instructions

Keeping your tablets and docking station clean is important both for the health and safety of users and to keep the tablets working properly.

### BEFORE CLEANING:



Power down the tablets and docking station prior to cleaning to avoid making unintended changes.



Do not spray liquids on the tablets or inside the docking station. If liquid does get inside, have a qualified technician check for any issues prior to powering back on.



A vacuum cleaner can be used to clean the inside of the docking station.



Do not wipe the tablets or the docking station with a cloth or sponge that can scratch the surface. Use a microfiber or lint-free cloth.

### TO CLEAN THE TABLETS:

- Use one of the recommended cleaning solutions to dampen a microfiber cloth or lint-free cloth.
- Place the cloth at the top of the screen and pull evenly from top to bottom.
- Dry with a clean microfiber cloth.

This method should also be used on the back and edges of the tablets and the docking station.



Antibacterial screen protectors are also available. Contact your EnvisionWare representative to learn more.

### RECOMMENDED CLEANING SOLUTIONS:

- Water and normal screen cleaners
- Isopropyl alcohol (<70% solution)
- Oxivir® Plus spray
- Isopropyl alcohol mixed with water
- UV light

### DO NOT USE THE FOLLOWING PRODUCTS:

- Methyl or ethyl
- Hand sanitizer
- Disinfectant wipes
- Thinner or benzene
- Window cleaner
- Hand soap or shampoo
- Sponge with abrasives
- Steel blades
- Lysol®
- Acid
- Detergents with fluoride or ammonia
- Paper